



# Technical Data Sheet



## **SG - 201** **Solvent Based Conductive XG-Ink**

SG-201 is an electrically conductive ink/coating formulated with XG Sciences' xGnP® Graphene Nanoplatelets for application by gravure printing. This product has an excellent adhesion to a variety of substrates. SG-201 provides an alternative to meet your printing needs without sacrificing performance.

XG-Solvent Based Ink SG-201 Typical Properties	
Sheet resistivity ( $\Omega/\text{sq}/\text{mil}$ )	<15
Density (lb/gal)	7.6
Drying (minutes @ 70 degrees Celcius)	5-10 minutes
Viscosity	100-125 cps
Solids (%)	18
Thinner	IPA

Note: The table shows anticipated typical properties for SG-201 based on specific controlled experiments in our labs and are not intended to represent the product specifications, detail of which are available upon request.

### **Mixing and Dilution**

Thoroughly mix SG-201 with an agitator or a paint shaker before use. If necessary, add thinner while mixing.

### **Drying**

Coated parts should be dried at 70 degrees Celcius for 5-10 minutes immediately after printing.

### **Clean up Solvent**

IPA

### **Safety and Handling**

For Safety and Handling information pertaining to this product, read the Material Safety Data Sheet (MSDS).

### **Storage and Shelf Life**

Container should be stored, tightly sealed in a clean and stable environment at room temperature. Avoid high heat or freezing. Shelf life of material in unopened containers is six months from the date of shipment. Some settling of solids may occur and compositions should be thoroughly mixed prior to use.

XG Sciences believes the information in this technical data sheet to be accurate at publication. XG Sciences does not assume any obligation or liability for the information in this technical data sheet. No warranties are given. All implied warranties of fitness for a particular purpose are expressly excluded. No freedom from infringement of any patent owned by XG Sciences or other is to be inferred. XG Sciences encourages its customers to review their manufacturing processes and applications for xGnP Graphene Nanoplatelets from the standpoint of human health and environmental quality to ensure that this material is not utilized in ways that it is not intended or tested. Product literature and safety data sheets should be consulted prior to use. Please contact XG Sciences or [www.xgsciences.com](http://www.xgsciences.com) for the most current technical information.

[www.xgsciences.com](http://www.xgsciences.com)

© 2012 XG Sciences, Inc. All rights reserved.

 **XG sciences**  
THE MATERIAL DIFFERENCE